

Automotive EMC testing with Keysight

11/1/2018

Jason Shen
RF/uW Applications Engineer


EMI is about unwanted interference



How to evaluate EMI emissions with a spectrum/signal analyzer ?


Getting started – Basic terms

EMI, EMS, EMC




Why bother?

EMC evaluation is along with your product NPI cycle



Product Development Cycle Including EMC Testing



← EMC Education →

← EMC diagnostic evaluation →

← Pre-Compliance testing →

← Compliance testing →

← Increasing flexibility to solve EMI problems

Increased cost to solve EMI problems →

Agenda

Update this text


10/31/2018
Page 5

- EMI pre-compliance measurement overview
- Keysight EMI solutions

- EMI pre-compliance measurement overview
- Keysight EMI solutions

Conducted Emissions

9 kHz – 30 MHz



Conducted Emissions Test Setup


Table:

- Surface area $> 1.5 \times 1 \text{ m}^2$
- Height $> 0.8 \text{ m}$
- A metal grounding panel must be placed on the surface of the table

Grounding panel:

- Size $> 2 \times 2 \text{ m}^2$
- 0.5 m margin against the other setups on the table
- Must connect to the ground
- Ground resistance $< 2 \text{ ohm}$

Compliance test needs be done in a shielded room



Other accessories of EMI testing



LISN: Line Impedance
Stabilization Network



Close Field Probe Set:
Diagnostics antennas




Current injection probe



EM-Clamp

Radiated Emissions Setup



The goal is to find and record the maximum emissions from the EUT by rotating the turn table, changing the polarity and the height of the antenna.

Accessories of an EMI testing - Radiated



Log Periodic Antenna:
200 to 1000 MHz



Biconical Antenna:
30 to 300 MHz




Double ridged horn antennas
18 GHz or even higher



Hybrid log periodic
Broadband
30 MHz to 2 GHz



Tripods: used to raise and
lower antennas



Rotating Table:
To rotate EUT for testing

About antenna factor (AF)

Very important in EMI measurement

- AF is defined as the ratio of the electric field strength to the voltage induced across the terminals of an antenna.
- Think of it as a “correction factor” for a given receiver
- For an electric field antenna (V/m, or $\mu\text{V/m}$):
 - Expressed in linear quantity: $AF = \frac{E}{V}$ (1/meter)
 - Expressed in log quantity: $AF = E_{\text{dB}\mu\text{V/m}} - V_{\text{dB}\mu\text{V}}$
- For a magnetic field antenna (A/m):
 - $AF = \frac{9.37}{\lambda \sqrt{G}}$ G: the antenna gain

Pre-compliance vs. Compliance

	Pre-compliance testing	Compliance Test
Purpose	To increase the confidence level at final compliance test	To achieve certificates (e.g. C-tick, CE, UL, KC, CCC, FCC)
Overall	Not identical to, but can simulate the standard procedure as much as possible	Must follow the standard procedure
Physical setup requirements	Can be done in house, throughout the design process	Must be done in test house (for certification)
	Can be done in a shielded room, or an open area	Must be in an anechoic chamber
	EMI receiver or spectrum analyzer	Must use an EMI receiver
	Simplified test setup	Must use standard test setup
Cost	Much less expensive, and quick turn-around	Very expensive and time consuming
Result	Will report an EMI risk	Will report an EMI failure
	Able to track to the interference source with a NF probe	Cannot tell where the failure comes from



CISPR 16-1-1 Compliant Receiver

A CISPR 16-1-1 receiver must have the following functionality in the range 9 kHz - 18 GHz:

- A normal +/- 2 dB absolute accuracy
- CISPR-specified resolution bandwidths (-6 dB)
- Peak, quasi-peak, EMI average, and RMS average detectors
- Specified input impedance with a nominal value of 50 ohms; deviations specified as VSWR
- Be able to pass product immunity in a 3 V/m field
- Be able to pass the CISPR pulse test (implies pre-selector below 1 GHz)
- Other specific harmonic and intermodulation requirements


About quasi-peak detection

- There are three commonly used detection modes for making EMI measurements, including peak, average, and quasi-peak detection.
- Why use Quasi-peak detection?
 - Used for CISPR based measurements.
 - weighting signals as a function of repetition rate.
 - Lower repetition rate noise has less “annoyance factor” and thus gets less emphasis
 - CISPR bandwidth: 200 Hz, 9 kHz, and 120kHz bandwidth.



Detection Modes

Peak $\geq$ Quasi-Peak $\geq$ Average



- EMI pre-compliance measurement overview
- Keysight EMI solutions

Keysight Analyzers

– Pre-compliance

- X series Analyzers

- N9000B CXA
- N9010B EXA
- N9020B MXA
- N9030B PXA
- N9040B UXA



- N934xC Handheld Analyzer



– Compliance

- EMI receiver



Introducing: N9048B PXE EMI Receiver

The new PXE EMI Receiver series enables you to make radiated and conducted emissions tests, certifying that a product meets local regulatory compliance standards.



- Determine if product meets local EMC standards
- Diagnose causes for compliance failures
- Troubleshoot product's emission problem areas

N9048A PXE EMI Receiver Offers World-Class EMI Measurement Capability

➤ Three frequency ranges

- 2 Hz – 3.6 GHz
- 2 Hz – 8.4 GHz
- 2 Hz – 26.5 GHz

➤ Fully CISPR Compliant

- CISPR bandwidths (6dB and impulse BW)
- Quasi-Peak, EMI-Avg and
- RMS-Avg detectors

➤ Fully MIL-STD-461 Compliant

- 6dB bandwidths
- Peak detector

➤ New RF Pre-Selector & LNA Design

- Enables you to tune out multiple frequencies and image responses while improving dynamic range
- Amplify your signal of interest without adding noise

➤ Most Competitive Sensitivity in the World



Front Panel and User Interface

10.6 inch **multi-touch screen**
simplifies measurement setup



Input 2
2 Hz to 1 GHz
Surge protected to 2 kW
(built-in limiter)

Navigate the interface
and help system using
the front-panel keys, or a
mouse and keyboard

Input 1
2 Hz to 3.6/8.4/26.5 GHz

RBWs for CISPR & MIL

Commercial (CISPR)

Bands	Frequency range	CISPR RBW
A	9 – 150 kHz	200 Hz
B	150 kHz – 30 MHz	9 kHz
C	30 – 300 MHz	120 kHz
D	300 MHz – 1 GHz	120 kHz
E	1 – 18 GHz	1 MHz

Military (MIL-STD-461)

Frequency range	RBW
30 Hz – 1 kHz	10 Hz
1 – 10 kHz	100 Hz
10 – 150 kHz	1 kHz
150 kHz – 30 MHz	10 kHz
30 MHz – 1 GHz	100 kHz
Above 1 GHz	1 MHz

Keysight Software


- Keysight Spectrum Analyzers have 2 EMI software applications
 - N6141x (EMI Measurement Application) and Option EMC

Comparison of EMI measurement application and Option EMC features

Feature	EMI Measurement Application	Option EMC
CISPR 16-1-1 detectors	•	•
CISPR 16-1-1 bandwidths	•	•
MIL-STD 461 bandwidths	•	
Log and linear display	•	
Signal list	•	
Scan table	•	
Simultaneous detectors	•	
Automatic limit testing	•	
Measure at marker	•	
Delta to limit	•	
Strip chart	•	
Step and swept scans	•	
Report generation	•	
Time domain scan ¹	•	
Monitor spectrum ¹	•	
Amplitude probability distribution (APD) ¹	•	
Disturbance analyzer (click measurements)	•	
UI commonality with MXE receiver	•	

Option EMC

Provides the essential capabilities on EMI interference analysis



Option EMC provides:

- CISPR 16-1-1 (2010) fully-compliant detectors
- CISPR band presets to 18 GHz
- Measure at marker with three detectors
- Tune and listen for signal discrimination

One-button EMI presets


Measurement parameters set according to CISPR bands

Option EMC (cont.)

Measure at marker with 3 detectors simultaneously

Measure at marker with three detectors:

- Peak
- Quasi-peak
- EMI average



Built-in CISPR and MiL-STD limit line

A list of commercial limits for recalling

The image displays two screenshots of the Keysight software interface, illustrating the process of recalling commercial limits.

Left Screenshot: The 'Limit' menu is open, showing a list of commercial limits. A red circle highlights the 'Limit' menu item. The list includes:

- AS-NZS
- BellCore
- DEF STAN
- DO-160
- EN
- FCC
- GB9254
- MIL-461
- VCCI

Right Screenshot: The 'Limit' menu is open, showing a list of commercial limits. A red circle highlights the 'Limit' menu item. The list includes:

- EN 55015, Cond, Control, Average.csv
- EN 55015, Cond, Control, Quasi-Peak.csv
- EN 55015, Cond, Load, Average.csv
- EN 55015, Cond, Load, Quasi-Peak.csv
- EN 55015, Cond, Mains, Average.csv
- EN 55015, Cond, Mains, Quasi-Peak.csv
- EN 55015, Rad, 30-300MHz (10m).csv
- EN 55015, Rad, 9kHz-30MHz, Loop=2m.csv
- EN 55015, Rad, 9kHz-30MHz, Loop=3m.csv
- EN 55015, Rad, 9kHz-30MHz, Loop=4m.csv

N6141x EMI measurement application

Runs inside signal analyzer



EMI precompliance test capabilities:

- Built-in CISPR and Mil-STD compliant BW, detectors and band presets
- Automated testing to regulatory limit lines with user-selected margins
- Amplitude corrections for antennas, LISNs, NF probes, etc

Measurement features:

- 3 simultaneous detectors (Peak, Quasi-peak, Average)
- Built-in signal list tracking those non-compliance emissions
- Strip chart for analysis of emissions versus time
- Supports precompliance “Click” measurements

Wrap up

EMI basics and EMI measurement

- ◆ Which standard(s) to follow? *Depends on what, where, and how of product* (Generally, start from CISPR 25 for vehicles)
- ◆ The conducted and radiated emissions can be captured and analyzed with a spectrum analyzer and corresponding accessories
- ◆ Keysight spectrum analyzers help you on EMI pre-compliance test

Understand the compromises/value in the precompliance scanning


It cannot duplicate the final compliance test, but it can tell you the EMI trend and the change of trend in your device

Back up

EMC standards

From international to commercial

Categories:



CISPR
standard
Structure:

Basic Standards

- Provide general and fundamental rules
- Serve as a reference but not applicable to specific products

Generic Standards

- Provide essential test requirements and procedure in a specific environment
- Also provide limits

Product Standards

- Apply to specific products or families of products
- Provides test procedures and limits for these products

Emissions regulations

Comparison of regulatory agency requirements

FCC	CISPR	EN's	Description
18	11	EN 55011	Industrial, scientific and medical equipment
—	12	—	Automotive
15	13	EN 55013	Broadcast receivers
	14	EN 55014	Household appliances/tools
	15	EN 55015	Fluorescent lights/luminaries
15	22	EN 55022	Information technology equipment
	—	EN61000-6-3,4	Generic emissions standards
	16	—	Measurement apparatus/methods
	25	EN 55025	Automotive component test

Emissions regulations in US

FCC regulatory agency requirements

Federal Communications Commission

Equipment Type

- Broadcast receivers
- Household appliances
- Fluorescent lights / luminaries
- Information technology / equipment (ITE)
- Industrial, scientific, and medical (ISM)
- Conducted measurements: 9 kHz – 30 MHz
- Radiated measurements: 30 MHz - 1000 MHz, 40 GHz

FCC

Part 15

Class A Industrial
Class B Residential

Part 18




Note:

FCC part 15 states that any digital device which uses timing pulses (clocks) in excess of 9kHz, must not unintentionally emit radiation over certain limits. This testing is required up to the 5th harmonic of the fastest clock but less than 40 GHz. For example, a computer or radio with a 1.2 GHz processor must meet FCC Class B limits up to 6 GHz.

FCC Part 18 requires devices that operate (transmit) from 30 MHz to above 1GHz test to 10th Harmonic, examples:

- 250 MHz 10th harmonic: 2.5 GHz
- 500 MHz 10th harmonic: 5.0 GHz
- 1.0 GHz 10th harmonic: 10 GHz
- 2.4 GHz 10th harmonic: 24 GHz

Source of EMI



From Natural power:

- thunder; volcano, typhoon
- electrostatic discharge
- sun, outer space
- ...


From Man-made Unintentional:

- Switching power supplies
- Switching frequencies and harmonics
- Load-dependent emissions
- Clock and Data
- High speed clocks, data, edges
- High speed interfaces
- Switching controls
- ...

From Man-made Intentional:

- Broadcasting, cellular communication
- Radar, GPS
- Wireless charging
- ...

About Antenna type

	Commercial electronics	Automotive electronics	Military
Frequency range	30 MHz – 1 GHz	10 kHz – 1 GHz	10 kHz – 18 GHz
Antenna type	Biconical Log periodic	Biconical Log periodic Whip antenna	Whip antenna Biconical 喇叭天线
 Log periodic antenna  Biconical antenna  Whip antenna  Horn antenna			

Recommended design practices

Recommended Design Practices: Device Selection

- Use lowest clock speed possible.
- *Use multiple clock oscillators instead of routing clock lines whenever possible.*
- Use minimum acceptable rise-time parts.
- Use low-ESR , low - ESL capacitors for decoupling/filtering.
- *Use multilayer PCBs whenever possible.*
- Always use toroidal transformers in switching power supplies.
- Watch out for DC saturation of ferrites in power supply lines.
- Use SMT parts whenever possible.
- Avoid IC sockets whenever possible.
- Avoid using ribbon cables for data or clock signals.
- Keep cables as short as possible.

Recommended Design Practices: PCB layout

- Segment board to separate high-frequency logic from low-frequency I/O as much as possible.
- Always route lines over ground/power plane "bridges" over segmentation "moats". The width of the bridges should extend at least 2 trace widths past outside traces.
- Ground the PCB to a metal plate parallel to it in a 2" grid. The ground plate should be as close to the PCB as possible, and should lip up to be higher than the PCB on the sides. The plate itself should be either the base of the enclosure or single-point grounded near the safety ("green-wire") ground attachment point.
- *If a 2-layer board is used, fill one side with ground as much as possible, and eliminate as much trace work from that side as possible.*
- Place decoupling capacitors as close to the IC Vcc and GND pins as possible -*even on analog parts* - we have seen Hall-effect sensor IC's oscillate at 40 MHz when no decoupling was used !
- Filters should always be place as close to the end of the trace as possible.
- I/O connector filters must go as close to the I/O port as possible; avoid ground planes between a common-mode filter and the connector it is filtering - the ground plane should stop at the circuit side of the CM choke.
- Buss lines, clock lines, and other periodic lines should be routed on layers adjacent to inner plane layers. Slower and low-susceptibility lines should be routed on outer layers.
- Always route clocks first and lock them. Avoid placing other lines within 2 trace widths of a clock line
- Ferrites and other filters should be reviewed to see if shapes can be used to allow replacement of the series elements with 0-ohm resistors at the prototype stage.
- Whenever possible, 45-degree bends should be used at corners.
- Minimize vias (connections between layers on a PCB).
- Do not route clock traces along edges of PCB or PCB segments.
- Allow at least 2 trace widths between edge-most trace and outside edge of power-plane.
- Treat Read/Write traces as clock traces.

Recommended Design Practices:

Mechanical design

- Try to provide an adjacent sheet metal plane with multiple attachments (every 2 inches recommended) to any PCB. Attachments (usually standoffs) should be short and wide as possible. If the product has a non-metallic enclosure, this "ground plate" is a requirement.
- Minimize longest side of any enclosure seam or opening. Greater than 2" is usually unacceptable.
- Allow for overlapping at seams.
- Do not allow paint to cover mating surfaces.
- Avoid dissimilar metals.
- All I/O connectors should be co-located.
- Avoid openings through which ESD can jump to electrical components. ESD can jump about 1/2 ", but can crawl almost 2" over plastic surfaces at 15kV.
- Ground all metal with short, wide ground bonds; the "green-wire" ground should not extend into the product interior more than 1.5".
- Avoid requiring large holes in PCB's.
- Allow for secure mounting of cables (up against metal whenever possible).
- Avoid long sections of metal which extend over electronics and are not grounded at short intervals.
- Use mechanical means for switches which would otherwise have long leads back to PCB.
- Avoid stacking PCBs or placing PCBs in parallel without having shielding wall in between.
- Avoid long lines to motors.
- Motor leads must be twisted, and should be run along metal as much as possible. Motors will usually require shielding.
- Review all sensor locations for ESD susceptibility. Sensor lines should be twisted and should be run along metal whenever possible.
- High-sensitivity analog circuitry will always require extremely tight shielding.

CISPR Product Groups


- **CISPR 11** - Industrial, Scientific, and Medical (ISM) Radio-Frequency Equipment
- **CISPR 12** - Vehicles, Motorboats, and Spark-Ignited Engine-Driven Devices
- **CISPR 13** - Sound and Television Broadcast Receivers and Associated Equipment
- **CISPR 14** - Household Appliances, Electric Tools, and Similar Apparatus
- **CISPR 15** - Electrical Lighting and Similar Equipment.
- **CISPR 17** - Suppression Characteristics of Passive Radio Interference Filters and Suppression Components.
- **CISPR 18** - Overhead Power Lines and High-Voltage Equipment
- **CISPR 20** - Sound and Television Broadcast Receivers and Associated Equipment
- **CISPR 21** - Interference to Mobile Radio communications
- **CISPR 22** - Information Technology Equipment–Radio Disturbance Characteristics
- **CISPR 24** - Information Technology Equipment–Immunity Characteristics
- **CISPR 25** - Receivers Used on Board Vehicles, Boats, and on
- **CISPR 32** – Multimedia devices emission testing (under development)
- **CISPR 35** – Multimedia devices immunity testing (under development)

Commercial EMC Standards and Entities - Examples

Country /Organization	Entity	Standards
IEC	CISPR 	CISPR Pub. xx
IEC	TC77 	IEC 6xxxx
EC	CENELEC 	EN 550xx
US	FCC, DoD 	FCC Part xx, MIL-STD. xxx
Canada	CSA 	ICES xxx
Australia/NZ	AS/NZS 	AS/NZS CISPR xx
Japan	VCCI 	J550xx
China (Mainland)	CCC, MoD 	GB xxxx- xxxx GJB xxx- xx (equivalent to Mil-STD)
Korea	MIC 	Equivalent to EN 550xx
Taiwan	BSMI 	CNS xxxx

Reference work flow:

Instrument Setup → Scan → Peak search → Measure



N6141x Measurement procedure

Step 1. Set up the scan table

The screenshot displays the 'EMI Receiver 1 Frequency Scan' window. The main area is a 'Scan Table' with columns for Range 1 through Range 5. The 'Meas Setup' button in the top right corner is highlighted with a red box and a yellow circle with the number 1. The 'Scan Table' button in the right-hand menu is highlighted with a red box and a yellow circle with the number 2.


	Range 1	Range 2	Range 3	Range 4	Range 5
Start Freq	9.000 kHz	150.000 kHz	30.000000 MHz	300.000000 MHz	300.000000 MHz
Stop Freq	150.000 kHz	30.000000 MHz	300.000000 MHz	1.000000000 GHz	1.000000000 GHz
RBW	200 Hz	9 kHz	120 kHz	120 kHz	120 kHz
Dwell Time	4.10 ms	108 µs	6.73 µs	6.73 µs	6.73 µs
Step Size	100 Hz	4.500 kHz	60.000 kHz	60.003 kHz	60.003 kHz
Points/RBW	2	2	2	2	2
Atten	10 dB	10 dB	10 dB	10 dB	10 dB
Int Preamp	Off	Off	Off	Off	Off
RF Input	Input1	Input1	Input1	Input1	Input1
Scan Time	5.78 s	717 ms	30.3 ms	78.6 ms	78.6 ms

Press [Meas Setup] → {Scan table} to configure the measurement range, as well as other parameters, if needed


The X-series signal analyzer will set the EMI measurement parameters according to the scan table automatically

N6141x Measurement procedure

Step 2. Load limit line. Load correction data.



- Press [Recall] → {Limit} to load a pre-defined limit file
- Press [Recall] → {Correction} to load a pre-defined correction file



To edit a correction, press [Input/Output] → {Correction}, to manually edit correction data

N6141x Measurement procedure

Step 3. Scan, search, and measure

